

PROGRAMMING

1. Press status.

Time of Day
will appear.



Set **Time-of-Day**. *ALL MODELS.*

Press ▲ to increase or
▼ to decrease

2. Press status.



Set **Recharge Time**.
ALL MODELS.

Press ▲ to increase or
▼ to decrease

3. Press status.



Set **Salt Dosage** (3-15 lb for 9",
5-24 lb for 12"). *ALL MODELS.*

Press ▲ to increase or
▼ to decrease


4. Press status.



Set **Backwash Time**
(5-40 minutes). *ALL MODELS.*

Press ▲ to increase or
▼ to decrease.


5. Press status.



Set **Brine Rinse Time** (37-85
minutes for 9", 35-89 minutes
for 12"). *ALL MODELS.*

Press ▲ to increase or
▼ to decrease.


6. Press status.



Set **Hardness Level** (1-75 gpg
for 9", 1-99 gpg for 12").
METER MODELS ONLY.

Press ▲ to increase or
▼ to decrease.

7. Press status.



Set **Regeneration Interval** (1-42
days). *TIME CLOCK MODELS
ONLY.*

Press ▲ to increase or
▼ to decrease.